MINIX
Next Generation Computing

NEO Z64

64-bit Mini PC
for Android™

Multi-Language Setup Guide
English/Deutsch/中文/日本/Русский

Specifications

Processor	Intel Z3735F (64-bit)
GPU	Intel HD Graphics
System Memory	2GB DDR3L
Storage	32GB eMMC
OS Support	Android™ KitKat 4.4.4 (pre-installed) or Windows 8.1 (not installed)
Connectivity	802.11n Wi-Fi, Bluetooth 4.0
USB	2 x USB 2.0 Ports
Video Output	HDMI™ 1.4
Audio Output	Via HDMI™ 1.4, 3.5mm stereo jack
Misc.	IR Remote Control
Dimensions	115x115x20mm

Contents

MINIX NEO Z64

MINIX IR-Remote

Power Adapter
(DC 5V, 3A)

HDMI Cable

Thank you for purchasing the MINIX NEO Z64.

The NEO Z64 transforms any conventional TV or LCD monitor with a HDMI™ connection into a fully functioning 64-bit Mini PC for Android™. Fully equipped with Android™ 4.4.4 OS (KitKat) the NEO Z64 brings the complete Android™ experience to the big screen: offering web browsing, XBMC, Full 1080p HD video playback and streaming, Internet radio, gaming and much more.

More hints, tips and useful information can be found on the official MINIX Forum: www.minixforum.com

Overview



Overview



Overview

IR Receiver - Use with the included MINIX IR-Remote to control the NEO Z64.

Power LED - The LED glows blue when the NEO Z64 is on.

Power button - To power on the NEO Z64, press and hold the power button for 1-2 seconds until the power LED glows. To power off the NEO Z64, press and hold the power button and the display will prompt out the power off options, select OK to confirm your choice. Alternatively, hold the power button for 8 seconds to force power off.

Micro SD card slot - Increase the storage size or read files directly from a Micro SD card, supports up to 64GB max.

Earphone Jack - Connect to an external audio output device such as earphones etc...

Overview

Ethernet Jack - Connect the Ethernet cable for internet access. If you need advanced settings such as VPN, go into the settings page at: "Settings" > "More..". While connected with the Ethernet cable, the NEO Z64 can be used as a router and also a Wi-Fi hotspot: if you need to use the Wi-Fi hotspot feature, please make sure that the Wi-Fi feature is OFF before you enable the Wi-Fi hotspot service at: "Settings" > "More".

DC 5V Power-in Jack - Connect the 5V power adapter supplied in the package to this port. The NEO Z64 requires less than 1A to operate, however the included power adapter provides 3A, in consideration that you may require extra to connect other power-drawing external devices such as an external hard drive.

USB 2.0 Ports - Connect an external USB device to the NEO Z64, such as USB flash drive, receiver of wireless keyboard and mouse, USB wired mouse, receiver of wireless headset, MINIX branded air-mouse / gyro-mouse etc..

HDMI port - Connect the NEO Z64 to the HDMI port of a high-definition TV or PC monitor using an HDMI cable..

Control

Different Control Methods - You may control the NEO Z64 with the following input devices:

1.) Wired mouse;
2.) 2.4GHz USB wireless mouse and keyboard set;
3.) 2.4GHz USB air-mouse / gyro-mouse (MINIX branded mouses sold separately).
4.) MINIX IR-Remote (included).

Using the MINIX IR-Remote – Use the MINIX IR-Remote to control the NEO Z64 settings and navigate your content. Make sure there are no obstructions between the MINIX IR-Remote and the NEO Z64.

IR-Remote Functions

* Requires two AAA batteries.

≡	**MENU**	Call out the options menu for your current screen or running application
⌂	**HOME**	Return to the home screen (choice of launcher required)
⏻	**POWER**	To wake up from or put the MINIX NEO Z64 into sleep mode
↩	**BACK**	Return to the previous screen running or cancelling an activity
−	**VOLUME DOWN**	Adjust the system volume down
+	**VOLUME UP**	Adjust the system volume up
∧	**UP**	Move upward
‹	**LEFT**	Move left
›	**RIGHT**	Move right
∨	**DOWN**	Move downward
⏎	**OK**	To confirm a particular action, or as an "Enter" key
⚙	**SETTINGS**	Call out the basic settings menu

Basic Setup

What you need:

High-Definition TV or PC monitor - That can display 720p or 1080p video with at least one HDMI input.

HDMI Cable - To connect the NEO Z64 to your TV (HDMI cable included).

Wireless Network - A wired network cable or an 802.11 a, b, g, or n Wi-Fi wireless network (wireless video streaming requires 802.11g or n), your wireless network name and password.

Software and accounts - To play content (videos, photos, music) from a smartphone or PC on the NEO Z64 you will need:

- A UPnP/DLNA software pre-loaded on your smartphone or PC..
- A Google account to sign-in to Google Play Store to download the corresponding applications (e.g. iMediaShare, eHomeMediacenter) necessary for streaming the content from a smartphone or PC..
- Other accounts may be required for full access to some internet contents.

Basic Setup

The MINIX NEO Z64 connects to your TV or PC monitor through an HDMI port that delivers both audio and video. Before you setup the NEO Z64, look at the ports on the side/back of your TV or PC monitor to ensure you have the right cable:

- HDMI cable: You can connect the NEO Z64 to a HDTV or home theater receiver that has a HDMI port, using the HDMI cable for video and audio.

Step 1: Connecting the cable

1. Connect one end of the HDMI cable to the HDMI port of your TV / PC monitor.
2. Connect the other end of the cable to the HDMI port of the NEO Z64.

Step 2: Connecting the power

- Connect the 5V power adapter supplied in the package to the relevant port. Press and hold the power button for 1-2 seconds to power on the NEO Z64, the blue power LED should then glow.

Step 3: Turn on your TV / PC monitor and select the input

- Simply turn on your TV or PC monitor and select the corresponding HDMI port connected to the NEO Z64.

Basic Setup

Language Setup

You may choose the desired system language by following these steps:
Launcher Home Screen > Settings > Language & Input > Language
The default language is English, you may choose your desired language and confirm.

Time Zone Setup

You should adjust the time zone according to your current location by the following steps:
Launcher Home Screen > Settings > Date & Time > Select Time Zone
Choose your time zone and confirm.

Wi-Fi Setup (basic)

To connect to your wireless network follow these steps:
Launcher Home Screen > Settings > Wi-Fi > Check the option "To see available networks turn Wi-Fi on"
Wi-Fi will turn on and automatically scan the wireless networks available, then select the wireless network that you wish to connect to and confirm, key in the password at the Wi-Fi network when the virtual keyboard prompts, finally hit the "Connect" button.

Google Play Store

Sign-in to your Google Account.
Launch the Google Play Store by the following steps:
Launcher Home Screen > Google Play Store, select and confirm.

To use the Google Play Store you will need a Google Account. If you already have a Google Account, select "Sign in" and login with your Google Account. If you don't have a Google Account yet, select "Get a Google Account" and complete the rest of the process.

Upon completion of the sign-in process you will be brought to the Google Play Store, allowing you to download and install the applications you want. Alternatively, if you cannot find the application you need on the Google Play Store because of language restriction, location restriction or other reasons: you may look for and download the application files in the form of ".apk" from the internet and install them through the "ApkInstaller", which is pre-loaded in the system.

XBMC

XBMC is a media player that allows users to play and view most videos, music, such as podcasts from the internet, and all common digital media files from local and network storage media.

For more information and instructions regarding XBMC please visit:
www.wiki.xbmc.org

Copyright © 2014 MINIX Tech. All rights reserved.

No part of this guide, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of MINIX. This clause does not apply to such software which is licensed under the General Public License ("GPL") or other Free Open Source Licenses. Copies of the respective license terms, and where required an offer to provide the respective source code, are included in the product.

Google, Android, Gmail, Google Maps, Chrome, Google Play, YouTube, Google+, and other trademarks are property of Google Inc. A list of Google trademarks is available at http://www.google.com/permissions/guidelines.html. MINIX and the MINIX logo are trademarks of MINIX Tech. All other marks and trademarks are properties of their respective owners.

The content of this guide may differ in some details from the product or its software.

All information in this documentation is subject to change without notice.

CE FC

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

MINIX
Next Generation Computing

NEO Z64

Benutzerhandbuch

Vielen Dank für Ihren Kauf des MINIX NEO Z64.

Bitte folgen Sie dieser Anleitung zur Einrichtung Ihres Geräts.

Der MINIX NEO Z64 ist ein revolutionärer Smart Media Hub, basierend auf einem Intel Z3735F Prozessor mit der Intel HD Graphics und dem aktuellen Android Betriebssystem. Nach Anmeldung im Google Play Store können Sie Ihre Lieblings-Apps herunterladen und direkt auf dem NEO Z64 installieren.
YouTube, Internet Radio und zahlreiche andere Apps stehen im Google Play Store zur Verfügung. Alternativ können Sie auch Apps von Drittanbietern herunterladen und mit dem vorinstallierten Apkinstaller installieren.

Der Z64 ist ausgestattet mit Ethernet- Bluetooth und Wi-Fi Verbindung; Sie können das Gerät mit vielen an Ihrem Netzwerk angeschlossenen Geräten verbinden und deren Inhalte teilen, z.B. Videos, Musik und Fotos.

Verbinden

Verbinden

Verbinden

IR Empfänger
Hiermit verbindet sich die mitgelieferte MINIX Fernbedienung für die Bedienung des MINIX NEO Z64.

Power LED
Die LED leuchtet bei eingeschaltetem MINIX NEO Z64.

EIN/AUS Schalter
Um den MINIX NEO Z64 einzuschalten, drücken Sie für 1-2 Sekunden den EIN/AUS Schalter, bis die Power LED leuchtet. Um den MINIX NEO Z64 auszuschalten, drücken Sie den EIN/AUS Schalter, bis Sie über das Display aufgefordert werden, dies zu bestätigen. Bestätigen Sie dies nun ODER halten Sie den EIN/AUS Schalter für 8 Sekunden gedrückt, um das Ausschalten zu erzwingen, bis die LED erlischt.

Kopfhörer Anschluss
Verbinden Sie ein externes Audiogerät, z.B. Kopfhörer oder Lautsprecher.

SD/MMC Karten Steckplatz
Erweitern Sie den Speicherplatz oder greifen Sie auf Dateien auf einer SD/MMC Speicherkarte zu, unterstützt werden Karten bis max. 64GB.

Verbinden

HDMI Anschluss
Verbinden Sie den MINIX NEO Z64 mit dem HDMI Port eines HD-fähigen TV Geräts oder Monitors mittels eines HDMI Kabels.

USB 2.0 Ports
Verbinden Sie externe USB Geräte mit dem MINIX NEO Z64, wie USB-Speichersticks, Empfänger für kabellose Tastatur und Maus, USB Maus, Empfänger von kabellosen Kopfhörern, etc ..

Eingang Netzteilkabel
Verbinden Sie das im Lieferumfang enthaltene 5V Netzteil mit diesem Eingang. Der MINIX NEO Z64 benötigt selbst weniger als 1A, dennoch haben wir ein Bis 3A ausgelegtes 5 Volt Netzteil beigefügt, um auch externe stromhungrige Geräte, wie z.B. Festplatten, mit genügend Power zu versorgen..

Verbinden

Ethernet Anschluss
Alternativ zum Wi-Fi Anschluss können Sie diesen LAN Anschluss mit Ihrem Netzwerk per LAN-Kabel für den Zugang zum Internet verbinden.
Für erweiterte Einstellungen, wie etwa VPN, navigieren Sie zu den Einstellungen bei Einstellungen -> Mehr...
Während der MINIX NEO Z64 per LAN Kabel mit dem Internet verbunden ist, kann der NEO Z64 als Router und als Wi-Fi Hotspot genutzt werden.
Wenn Sie die Wi-Fi Hotspot Eigenschaft nutzen möchten, muss der Wi-Fi Empfang des NEO Z64 AUSGESCHALTET sein,
bevor Sie den Wi-Fi Hotspot bei Einstellungen -> Mehr..., einrichten.

Copyright © 2014 MINIX Tech. Alle Rechte vorbehalten.

Kein Teil dieses Handbuchs, einschließlich der darin beschriebenen Produkte und Software, darf in irgendeiner Form oder mit irgendwelchen Mitteln vervielfältigt, übertragen, überschrieben, in einem Daten-abfragesystem gespeichert oder in irgendeine Sprache übersetzt werden, ohne die ausdrückliche schriftliche Genehmigung von Minix, außer durch den Käufer zum Zweck der Datensicherung. Diese Klausel gilt nicht für solche Software, die unter der General Public License ("GPL") oder anderen Free Open-Source-Lizenzen lizenziert ist. Kopien der jeweiligen Lizenzbedingungen, und, wo erforderlich, ein Angebot, um den jeweiligen Quellcode zu liefern, sind im Produkt enthalten.

Google, Android, Gmail, Google Maps, Chrome, Google Play, YouTube, Google+, und andere Warenzeichen sind Eigentum der Google Inc.
Eine Liste der Google-Marken finden Sie unter
http://www.google.com/permissions/guidelines.html.
MINIX und das MINIX Logo sind Warenzeichen von MINIX Tech.
Alle anderen Marken und Warenzeichen sind Eigentum ihrer jeweiligen Inhaber.

Der Inhalt dieser Anleitung kann sich in einigen Details von dem Produkt oder seiner Software unterscheiden. Alle Informationen in diesem Dokument können sich ohne vorherige Ankündigung ändern.

CE FC

MINIX
Next Generation Computing

NEO Z64

64-bit Mini PC
for Android™

Guía de configuración multilingüe
English/Deutsch/中文/日本/Русский

Especificaciones

Procesador	Intel Z3735F (64-bit)
GPU	Intel HD Graphics
Memoria del sistema	2GB DDR3L
Almacenamiento	32GB eMMC
Soporte del SO	Android™ KitKat 4.4.4 (preinstalado) o Windows 8.1 (no instalado)
Conectividad	802.11n Wi-Fi, Bluetooth 4.0
USB	2 x USB 2.0 Ports
Salida de vídeo	HDMI™ 1.4
Salida de audio	Vía HDMI™ 1.4, conector estéreo de 3.5mm
Misc.	Mando a distancia IR
Dimensiones	115x115x20mm

Contenido

MINIX NEO Z64

MINIX IR-Remote

Adaptador de corriente
(DC 5V, 3A)

Cable HDMI

Gracias por comprar el MINIX NEO Z64.

El NEO Z64 transforma cualquier televisor o monitor LCD convencional con conexión HDMI™ en un PC Mini de 64-bit totalmente funcional para Android™. Totalmente equipado con Android™ 4.4.4 OS (KitKat), el NEO Z64 ofrece la experiencia completa de Android™ en la gran pantalla: navegación web, XBMC, reproducción y streaming de vídeo Full HD 1080p, radio por Internet, juegos y mucho más.

Más consejos, trucos e información útil se pueden encontrar en el foro oficial de MINIX: www.minixforum.com

Overview

Overview

Overview

IR Receiver - Use with the included MINIX IR-Remote to control the NEO Z64.

Power LED - The LED glows blue when the NEO Z64 is on.

Power button - To power on the NEO Z64, press and hold the power button for 1-2 seconds until the power LED glows. To power off the NEO Z64, press and hold the power button and the display will prompt out the power off options, select OK to confirm your choice. Alternatively, hold the power button for 8 seconds to force power off.

Micro SD card slot - Increase the storage size or read files directly from a Micro SD card, supports up to 64GB max.

Earphone Jack - Connect to an external audio output device such as earphones etc...

Overview

Ethernet Jack - Connect the Ethernet cable for internet access. If you need advanced settings such as VPN, go into the settings page at: "Settings" > "More...". While connected with the Ethernet cable, the NEO Z64 can be used as a router and also a Wi-Fi hotspot: if you need to use the Wi-Fi hotspot feature, please make sure that the Wi-Fi feature is OFF before you enable the Wi-Fi hotspot service at: "Settings" > "More".

DC 5V Power-in Jack - Connect the 5V power adapter supplied in the package to this port. The NEO Z64 requires less than 1A to operate, however the included power adapter provides 3A, in consideration that you may require extra to connect other power-drawing external devices such as an external hard drive.

USB 2.0 Ports - Connect an external USB device to the NEO Z64, such as USB flash drive, receiver of wireless keyboard and mouse, USB wired mouse, receiver of wireless headset, MINIX branded air-mouse / gyro-mouse etc..

HDMI port - Connect the NEO Z64 to the HDMI port of a high-definition TV or PC monitor using an HDMI cable..

Control

Different Control Methods - You may control the NEO Z64 with the following input devices:

1.) Wired mouse;
2.) 2.4GHz USB wireless mouse and keyboard set;
3.) 2.4GHz USB air-mouse / gyro-mouse (MINIX branded mouses sold separately).
4.) MINIX IR-Remote (included).

Using the MINIX IR-Remote – Use the MINIX IR-Remote to control the NEO Z64 settings and navigate your content. Make sure there are no obstructions between the MINIX IR-Remote and the NEO Z64.

Funciones del mando a distancia IR

* Requiere dos baterías AAA.

≡	**MENU**	Llama al menú de opciones para la pantalla o aplicación en ejecución
⌂	**HOME**	Vuelve a la pantalla de inicio (se requiere un selector)
⏻	**POWER**	Para despertar o poner el MINIX NEO Z64 en modo de suspensión
↩	**BACK**	Vuelve a la pantalla anterior o cancela una actividad
−	**VOLUME DOWN**	Ajusta el volumen del sistema
+	**VOLUME UP**	Ajusta el volumen del sistema
∧	**UP**	Mueve hacia arriba
‹	**LEFT**	Mueve hacia la izquierda
›	**RIGHT**	Mueve hacia la derecha
∨	**DOWN**	Mueve hacia abajo
⏎	**OK**	Para confirmar una acción concreta, o como una tecla "Enter"
⚙	**SETTINGS**	Llama al menú de configuración básica

Basic Setup

What you need:

High-Definition TV or PC monitor - That can display 720p or 1080p video with at least one HDMI input.

HDMI Cable - To connect the NEO Z64 to your TV (HDMI cable included).

Wireless Network - A wired network cable or an 802.11 a, b, g, or n Wi-Fi wireless network (wireless video streaming requires 802.11g or n), your wireless network name and password.

Software and accounts - To play content (videos, photos, music) from a smartphone or PC on the NEO Z64 you will need:

- A UPnP/DLNA software pre-loaded on your smartphone or PC..
- A Google account to sign-in to Google Play Store to download the corresponding applications (e.g. iMediaShare, eHomeMediacenter) necessary for streaming the content from a smartphone or PC..
- Other accounts may be required for full access to some internet contents.

Basic Setup

The MINIX NEO Z64 connects to your TV or PC monitor through an HDMI port that delivers both audio and video. Before you setup the NEO Z64, look at the ports on the side/back of your TV or PC monitor to ensure you have the right cable:

- HDMI cable: You can connect the NEO Z64 to a HDTV or home theater receiver that has a HDMI port, using the HDMI cable for video and audio.

Step 1: Connecting the cable

1. Connect one end of the HDMI cable to the HDMI port of your TV / PC monitor.
2. Connect the other end of the cable to the HDMI port of the NEO Z64.

Step 2: Connecting the power

- Connect the 5V power adapter supplied in the package to the relevant port. Press and hold the power button for 1-2 seconds to power on the NEO Z64, the blue power LED should then glow.

Step 3: Turn on your TV / PC monitor and select the input

- Simply turn on your TV or PC monitor and select the corresponding HDMI port connected to the NEO Z64.

Basic Setup

Language Setup

You may choose the desired system language by following these steps:
Launcher Home Screen > Settings > Language & Input > Language
The default language is English, you may choose your desired language and confirm.

Time Zone Setup

You should adjust the time zone according to your current location by the following steps:
Launcher Home Screen > Settings > Date & Time > Select Time Zone
Choose your time zone and confirm.

Wi-Fi Setup (basic)

To connect to your wireless network follow these steps:
Launcher Home Screen > Settings > Wi-Fi > Check the option "To see available networks turn Wi-Fi on"
Wi-Fi will turn on and automatically scan the wireless networks available, then select the wireless network that you wish to connect to and confirm, key in the password at the Wi-Fi network when the virtual keyboard prompts, finally hit the "Connect" button.

Google Play Store

Sign-in to your Google Account.
Launch the Google Play Store by the following steps:
Launcher Home Screen > Google Play Store, select and confirm.

To use the Google Play Store you will need a Google Account. If you already have a Google Account, select "Sign in" and login with your Google Account. If you don't have a Google Account yet, select "Get a Google Account" and complete the rest of the process.

Upon completion of the sign-in process you will be brought to the Google Play Store, allowing you to download and install the applications you want. Alternatively, if you cannot find the application you need on the Google Play Store because of language restriction, location restriction or other reasons: you may look for and download the application files in the form of ".apk" from the internet and install them through the "ApkInstaller", which is pre-loaded in the system.

XBMC

XBMC is a media player that allows users to play and view most videos, music, such as podcasts from the internet, and all common digital media files from local and network storage media.

For more information and instructions regarding XBMC please visit:
www.wiki.xbmc.org

Copyright © 2014 MINIX Tech. All rights reserved.

No part of this guide, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of MINIX. This clause does not apply to such software which is licensed under the General Public License ("GPL") or other Free Open Source Licenses. Copies of the respective license terms, and where required an offer to provide the respective source code, are included in the product.

Google, Android, Gmail, Google Maps, Chrome, Google Play, YouTube, Google+, and other trademarks are property of Google Inc. A list of Google trademarks is available at http://www.google.com/permissions/guidelines.html. MINIX and the MINIX logo are trademarks of MINIX Tech. All other marks and trademarks are properties of their respective owners.

The content of this guide may differ in some details from the product or its software.

All information in this documentation is subject to change without notice.

CE FC

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

MINIX
Next Generation Computing

NEO Z64

64 bitная
приставка на базе Android™

Руководство по установке

Благодарим Вас за покупку MINIX NEO Z64.

NEO Z64 превратит любой обычный телевизор или ЖК-монитор с HDMI в ИК-пультом Minix для управления устройством
умный телевизор или компьютер. С установленной операционной системой Android 4.4 OS (KitKat), NEO Z64 несет все преимущества Android систем на большие экраны: предлагая возможности просмотра сайтов, воспроизведение видео в формате FullHD 1080p, потокового интернет-радио, HD и многое другое.

эксклюзивная версия XBMC, предустановленная на устройстве, обеспечивает аппаратную поддержку декодирования основных аудио и видео форматов и использует оптимальные настройки.

YouTube, Vkontakte, интернет-радио и множество других приложений доступно для скачивания. Так же вы можете устанавливать приложения из других источников таких как USB flash или домашняя сеть.

Устройство имеет возможность Ethernet, Bluetooth и Wifi подключений. Вы можете подключится к общим медиа ресурсам вашей домашней сети для просмотра видео или прослушивания музыки.

Подсказки, советы и полезную информацию вы сможете найти на официальном форуме MINIX: www.minixforum.com

Внешний Вид



Внешний Вид



Внешний Вид

ПриемникИКиспользуйтеинтегрированныйИК-приемникнаместес ИК-пультомMINIXдлядистанционногоуправления.

Индикатор питания
Индикатор питания зажжется синим цветом,еслиустройство включено

Кнопка питания

Для выключения приставки, нажмите и держите кнопку питания 1-2 секунды, пока индикатор питания не зажжется.Для выключения, нажмите и удерживайте кнопку питания,дождавшись на экране диалога выключения и нажмите кОК для подтверждения; или удерживайте кнопку питания более 8 секунд, для аппаратного выключения

Слот для карты SD-MMC
Используйте для подключения SD карт к вашему устройству.
Поддерживаются карты до 64ГБ включительно.

Аудиовыход
Подключите внешнее устройство для вывода звука, наушники либо колонки

Внешний Вид

Ethernet порт
Подключите Ethernet кабель для подключения устройства к локальной сети. При подключенном Ethernet кабеле, устройство может быть использовано как беспроводная точка доступа

Разъем питания
Подключите адаптер питания 5В к этому порту. Устройству требуется минимум 1А для работы. Блок питания из комплекта поставки обеспечивает 3В/3А, позволяя подключениевнешних USB шуструйств бесдополнительного питания.

USB 2.0 порт
Подключите USB устройства к приставке, внешние жесткие диски,USB мышки и клавиатуры (вам возможно понадобится использовать 2 порта USB для подключения внешних жестких дисков)

HDMI порт
Подключите устройство к HDMI порту телевизора либо монитора, используя hdmi кабель

Bedienung

Diverse Möglichkeiten der Bedienung
Sie können Ihren MINIX NEO Z64 mit folgenden Eingabegeräten bedienen:
1.) USB Kabelmaus
2.) 2.4GHz USB Funktastatur- und -maus Set
3.) 2.4GHz USB kabellose Airmouse Fernbedienung / Keyboard (MINIX NEO A2 Lite, MINIX NEO A2, MINIX NEO M1, separat erhältlich)
4.) MINIX Infrarot Fernbedienung (wird mitgeliefert)

Die MINIX Fernbedienung
Nutzen Sie Ihre MINIX Fernbedienung, um Einstellungen vorzunehmen und zu navigieren. Stellen Sie sicher, dass keine Hindernisse den Empfang zwischen Fernbedienung und MINIX NEO Z64 beeinträchtigen.

Funktionen der MINIX Fernbedienung

* benötigt zwei AAA batterien.

≡	**MENU**	Aufrufen des Optionsmenüs des aktuellen Screens oder der laufenden App
⌂	**HOME**	Zurück zum Home Screen mit Auswahl des Launchers
⏻	**POWER**	Hiermit wird der Sleep Mode/Schlafmodus des MINIX NEO Z64 aktiviert bzw. deaktiviert
↩	**ZURÜCK**	Zurück zum vorigen aktiven Screen oder Beenden einer Aktivität
−	**VOLUME DOWN**	Absenken der Lautstärke
+	**VOLUME UP**	Erhöhen der Lautstärke
∧	**HOCH**	Nach oben bewegen
‹	**RECHTS**	Nach rechts bewegen
›	**LINKS**	Nach links bewegen
∨	**UNTEN**	Nach unten bewegen
⏎	**OK**	Bestätigen einer Eingabe, und „Enter/Eingabe" Taste
⚙	**SETTINGS**	Aufrufen des Settingsmenü.

Erste Schritte

Was benötigt wird
Um den MINIX NEO Z64 zu benutzen, brauchen Sie Folgendes:

High Definition TV / PC Monitor
Ein HD-fähiges TV Gerät oder PC Monitor, welches 720p or 1080p Video wiedergeben kann mit einem freien HDMI Eingang.

Kabel
Ein HDMI Kabel, um den MINIX NEO Z64 mit Ihrem TV zu verbinden.

Netzwerk
Ein Netzwerkkabel als Verbindung zu Ihrem Router oder ein 802.11 a, b, g, o WLAN Netzwerk (Wireless Video Streaming benötigt 802.11 g oder n), den Namen und das Passwort Ihres WLANs.

Software und Nutzerkonten
Um Inhalte (Videos, Fotos, Musik) von einem Smartphone oder PC auf Ihrem MINIX NEO Z64 wiederzugeben, brauchen Sie:
- installierte UPnP/DLNA Software installiert auf Smartphone oder PC
- Einen Google Account für die Anmeldung im Google Play Store, um die entsprechenden Apps herunterzuladen (z.B. iMediaShare, eHomeMediaCenter), die für das Streaming des Inhalts von Smartphone oder PC benötigt werden.
- Ggf. weitere weitere Nutzerkonten für den vollen Zugang zu weiteren Webinhalten benötigt.

Erste Schritte

Einrichten des MINIX NEO Z64
Der MINIX NEO Z64 wird über den HDMI Port mit Ihrem HDMI-fähigen TV oder PC Monitor verbunden, wobei sowohl Bild als auch Ton mittels eines HDMI Kabels übertragen werden. Bevor Sie den MINIX NEO Z64 einrichten, prüfen Sie bitte die seitlichen/hinteren Anschlüsse Ihres TV / PC Monitors, um sicher zu gehen, dass Sie das richtige Kabel haben:

- HDMI Kabel: Sie können den MINIX NEO Z64 damit mit einem HDTV Gerät oder Home Theater Receiver mit HDMI Anschluss verbinden, das HDMI Kabel überträgt sowohl Bild as auch Ton.

Schritt 1: Verbinden der Kabel
1. Verbinden Sie ein Ende des HDMI Kabels mit dem HDMI Anschluss Ihres TV/PC Monitors.
2. Verbinden Sie das andere Ende des HDMI Kabels mit dem HDMI Anschluss des MINIX NEO Z64.

Schritt 2: Anschließen der Stromquelle
Verbinden Sie das mitgelieferte 5V Netzteil mit dem MINIX NEO Z64. Drücken Sie für 1-2 Sekunden den EIN/AUS Schalter, um den MINIX NEO Z64 zu starten, bis die blaue Power LED leuchtet.

Schritt 3: Anschalten des TV / Monitors und Wahl des Eingangs
Schalten Sie einfach Ihr TV Gerät oder Ihren PC Monitor an und wählen Sie den entsprechenden HDMI Port aus, an dem Ihr MINIX NEO Z64 angeschlossen ist.

Erste Schritte

Einstellung der Sprachversion

Sie können das Betriebssystem auf die gewünschte Systemsprache einstellen wie folgt:

Launcher Home Screen > Settings > Language & input > Language
Die voreingestellte Sprache ist Englisch, hier können Sie die gewünschte Sprache auswählen und bestätigen.

Einstellung der Zeitzone
Stellen Sie die Zeitzone Ihres Standorts ein wie folgt:

Übersicht Launcher Home Screen > Einstellungen > Datum & Uhrzeit > Zeitzone auswählen
Wählen Sie Ihre entsprechende Zeitzone aus.

Wi-Fi Einrichtung Grundeinstellungen

Verbinden Sie Ihren MINIX NEO Z64 mit Ihrem WLAN für die Verbindung mit dem Internet wie folgt:

Übersicht Launcher Home Screen > Einstellungen > WLAN > WLAN aktivieren, um verfügbare Netze abzurufen
Der MINIX NEO Z64 scannt nun die verfügbaren WLAN Netzwerke. Wählen Sie das entsprechende Netzwerk aus und bestätigen Sie die Auswahl, geben Sie das Passwort für Ihr WLAN Netzwerk ein, wenn die virtuelle Tastatur erscheint. Abschließend bestätigen Sie die Schaltfläche „Verbinden".

Google Play Store

Verbinden mit Ihrem Google Account

Aktivieren Sie den Zugang zum Google Play Store wie folgt:

Übersicht Launcher Home Screen > Google Play Store > anklicken

Um den Google Play Store nutzen zu können, brauchen Sie ein Google Nutzerkonto. Wenn Sie bereits einen Google Account haben, wählen Sie "Anmelden" und loggen Sie sich mit Ihren Zugangsdaten ein.
Wenn Sie noch kein Google Nutzerkonto haben, wählen Sie "Google Konto einrichten" und folgen Sie den Anweisungen.

Nach erfolgreicher Anmeldung werden Sie zum Google Play Store weiter geleitet, wo Sie die gewünschten Apps aussuchen und installieren können.

Falls Sie die gewünschte App im Google Play Store nicht finden, können Sie alternativ auch ".apk" Apps aus dem Internet herunterladen und mit dem vorinstallierten "Apkinstaller" installieren.

XBMC

XBMC ist ein Media-Player, mit der Benutzer von lokalen und Netzwerk-Speichermedien abspielen und die meisten Videos, Musik, wie Podcasts, aus dem Internet, und alle gängigen digitalen Mediendateien ermöglicht.

Für weitere Informationen und Hinweise auf Setup finden Sie unter: www.wiki.xbmc.org

Copyright © 2014 MINIX Tech. Alle Rechte vorbehalten.

Kein Teil dieses Handbuchs, einschließlich der darin beschriebenen Produkte und Software, darf in irgendeiner Form oder mit irgendwelchen Mitteln vervielfältigt, übertragen, überschrieben, in einem Daten- abfragesystem gespe